

HOW TO RECORD FROM KINDLE FIRE STICK/Other Streaming Devices/ Other Media TO **VHS**

Materials

- Blank VHS Tape
 - VCR
 - HDMI to AV Converter
 - RCA Cables
 - Kindle Fire Stick
 - TV
 - Extension Cord
 - USB Cables
 - RF Modulator
 - Portable Chargers
 - (2) RF Cables
 - (3) Different Remotes
1. You might want to plug up your TV.
 2. You might want to use your extension cord and plug it up.
 3. Hook the VCR up to the TV by using your RF Cable. Then plug up your VCR.
 4. Use your Second RF Cable for your VCR to hook your RF Modulator through the RF Output on your VCR. You might want to plug up your RF to RCA Converter first.
 5. You Might want to use and hook up your USB Cable to your portable wall charger to plug up your HDMI to RCA Converter. Then, Hook up your HDMI to RCA Converter to the RF Modulator.
 6. Hook up your [Kindle Fire Stick](#), [Chromecast](#), or your [Roku](#) as to your Input for your HDMI to RCA Converter. Then plug your [Kindle Fire Stick](#), [Chromecast](#), or [Roku](#).
 7. Turn the TV Channel to AV (If RCA Cable Compatible) (If you have an RF Cable, turn the TV Channel to TV.) Then press 3-0 on your TV Remote #1. Then Plug Up your VCR.(Older VCR's Hit Channel 3 on your VCR. (Newer VCR's) Hit the channel button to either Line 1 or Line 2 on your VCR
 8. Turn on your VCR. Then pop in a blank VHS Tape.
 9. If you have a recording tab on your tape and that the blank is used, pull the recording tab off. Then put Scotch tape on the recording tab's place.
 10. You might want to record an FBI Warning Screen and a logo for your VHS Tape and either NO previews or with Previews. Then hit the pause-record on your tape.
 11. Go to your apps. (You can use [YouTube](#), [Hulu](#), [Netflix](#), [Disney +](#), etc.) Then Hit Select.
 12. Once the app opens, search or scan through your YouTube Videos. Also, you can look for TV Shows and movies on [Hulu](#), [Netflix](#), [Disney +](#), etc. You can use your Kindle Fire Stick remote (Remote #2).
 13. Record your program. You can use your Remote #3.
 14. You might want to record a WSOD or BSOD or any VHS Screen of death. Then either a VHS Moaning sound or a double Moaning Sound VHS.
 15. Once the program reaches the end of the tape, the VCR will rewind the tape automatically. Then it will eject.
 16. After your recording is ejected, make sure you break off the recording tab or remove the homemade recording tab that you made yourself.
 17. You might want to check the film strip for any damage on your tape.

Other Ideas on How to Record from Kindle Fire Stick Streaming Device, or other Media to VHS

- Blank VHS Tape
 - VCR
 - HDMI to AV Converter
 - RCA Cables (One Spare, One For the VCR to the TV)
 - Kindle Fire Stick
 - TV
 - Extension Cord
 - USB Cables
 - Portable Chargers
 - (3) Different Remotes
 - RXII Digital Video Stabilizer (To Stop Macrovision blurs on your VHS Recording Pleasure)
 - Macrovision Copy-Protected VHS Tapes/DVD's
1. You might want to plug up your TV.
 2. You might want to use your extension cord and plug it up.
 3. Hook the VCR up to the TV by using your RCA Cable. Then Plug up your VCR.
 4. Use your Second RCA Cable for your VCR to hook your HDMI to AV Converter to the front or the back of your VCR.
 5. You Might want to use and hook up your USB Cable to your portable wall charger. Then You might want to plug up your HDMI to AV Converter.
 6. Hook up your [Kindle Fire Stick](#), [Chromecast](#), or your [Roku](#) as to your Input for your HDMI to RCA Converter. Then plug your [Kindle Fire Stick](#), [Chromecast](#), or [Roku](#).
 7. Turn the TV Channel to AV (If RCA Cable Compatible) (If you have an RF Cable, turn the TV Channel to TV.) Then press 3-0 on your TV Remote. Then Plug Up your VCR.(Older VCRs) Hit Channel 3 on your VCR. (Newer VCRs) Hit the channel button to either Line 1 or Line 2 on your VCR.
 8. Turn on your VCR (For Recording). Then pop in a blank VHS Tape. If you want to use a spare VCR (For Playing VHS Tapes that have Macrovision), you must use a spare RCA Cable, a 9V Battery, and an RXII Digital Video Stabilizer. Then Plug up your Spare VCR. (For Playing your tapes)
 9. If you have a copy-protected VHS Tape, use the RXII Digital Video Stabilizer to get rid of Macrovision blurs any black-and-white picture or other distortions. But first, put in a 9V battery inside your Digital Video Stabilizer by opening it before battery installation and closing it back after battery installation.
 10. Hook up your VCR (Video Output) that you want to play tapes onto the input of your RXII Digital Video Stabilizer. Then get a spare VCR that you can record VHS Tapes on (VCR Input) and hook it up to the output of your RXII Digital Video Stabilizer.
 11. If you have a recording tab on your tape and that the blank is used, pull the recording tab off. Then put Scotch tape on the recording tab's place.
 12. You might want to get a copy-protected VHS Tape or a VHS without Macrovision first. Then, You might want to record an FBI Warning Screen and a logo for your VHS Tape and either NO previews or with Previews. Then hit the pause-record on your tape. (either from VHS or YouTube)
 13. Go to your apps. (You can use [YouTube](#), [Hulu](#), [Netflix](#), [Disney +](#), etc.) Then Hit Select.
 14. Once the app opens, search or scan through your YouTube Videos. Also, you can look for TV Shows and movies on [Hulu](#), [Netflix](#), [Disney +](#), etc. You can use your Kindle Fire Stick remote (Remote #2).
 15. Record your program. You can use your Remote #3.
 16. You might want to record a WSOD or BSOD or any VHS Screen of death. Then either a VHS Moaning sound or a double Moaning Sound VHS.
 17. Once the program reaches the end of the tape, the VCR will rewind the tape automatically. Then it will eject.
 18. After your recording is ejected, make sure you break off the recording tab or remove the homemade recording tab that you made yourself.
 19. You might want to check the film strip for any damage on your tape.

WARNINGS: IT IS LEGAL TO MAKE ONLY ONE COPY OF YOUR OWN FAVORITE MOVIES/TV SHOWS FROM STREAMING DEVICES, VIDEOTAPES, OR VIDEO/ISCS You Buy at the store, but IT IS ILLEGAL TO DISTRIBUTE THOSE MOVIES/TV SHOWS.

Modes

SP	LP	EP/SLP
2 hours (T-120)	4 hours (T-120)	6 hours (T-120)
2hr 40 min (T-160)	5hr 20 min (T-160)	8 hours (T-160)
3hr 20 min (T-200)	6hr 40 min (T-200)	10 hours (T-200)

Another thing I forgot to include in this tutorial: You can use the RXII Digital Video Stabilizer to hook a VCR to another VCR. First, Hook Up your First VCR(record) onto the TV. Next, hook up the input of the VCR onto the output of the Stabilizer. Then, hook up the input of the stabilizer to the output of the VCR. Last, Hook up the recording VCR onto the playing VCR. After you do these hookups, you can copy macrovision Copy Protected VHS Tapes and DVDs (As well as Copy Protected TV Channels.)

